



COCO-MODO-V / A MULTI VOLTAGE V/AMICRO JUNCTION BOX FOR RED KOMODO

USER MANUAL

WE STRONGLY RECOMMEND THAT YOU READ THIS INSTRUCTION BEFORE USING YOUR BEBOB RED KOMODO-VMICRO ADAPTER! PLEASE KEEP THIS MANUAL FOR FUTURE REFERENCE

Features

- Mounts onto the back of the RED KOMODO
- 5 Outputs (1x USBA, 1x USBC, 1x DTap, 2x Lemo 2p)
- 1x Lemo 2p Input for Hotswap
- On-Off switch incl. LED for the accessories (5 outputs)
- Only one LED

Hotswap functionality

 Plug an external 7 – 17V DC power source into the Lemo 2p (only input) to swap the battery (Vmount or Goldmount) without interruption







Safety instructions

- Only for professional use! Keep the COCO-MODO-V/A out of reach of children and personnel that has not been instructed in the use!
- Use only with recommended batteries.
- Keep the COCO-MODO- V/A dry and do not immerse in water.
- Do not attempt to open or repair the COCO-MODO-V/A. Contact your dealer for help if it becomes defective.
- Handle with care! Do not throw! Do not drop!
- Remove the battery from the COCO-MODO- V/A when not in use for a longer period of time

Warranty

- The COCO-MODO-VMM is covered by a 2 years unconditional warranty on all parts.
- For warranty issues or if you have any additional questions, please contact the appropriate bebob distributor listed at www.bebob.de.

Specifications

Model	COCO-MODO-V / A
Battery Mount	Vmicro (or Amicro)
Voltages	5,0V/14,4V unreg. OUT / 7 to 17V (Camera IN)
Max. Draw	Depends on battery
Twist D-Tap	1 (14,4V unreg. / max. 5.0A)
USB-A Port	1 (5,0V / max. 2,0A)
USB-C Port	1 (5,0V / max. 1,0A)
Lemo 2p	2 (12V unreg. / max. 2,0A)
Lemo 2p DC IN	1 (7 to 17V) Hotswap
Operation Temperature	0°C – 40°C
Dimensions (WXHXD)	66 x 82,2 x 26,1 (mm)
Weight	0,225 kg