



ZOE-ENG-12 Zoom Remote

User Manual

WE STRONGLY RECOMMEND THAT YOU READ THIS INSTRUCTION BEFORE USING YOUR ZOE-ENG-12! PLEASE KEEP THIS MANUAL FOR FUTURE REFERENCE

Features

- 12 pin Hirose Plug
- Stepless speed control
- Record, Return

Functions

- **Zoom direction:** If you want change the direction of the zoom, please press the direction button while switching the Camera on.
- **Speed wheel:** The maximum zoom speed adjustment is step-less.
- **Record:** Starts/ends recording.
- **Return:** Identical function as the "RET" button on the lens.

Safety instructions

- Only for professional use! Keep Charger out of reach of children and personnel that has not been instructed in the use!
- Keep the ZOE dry and do not immerse in water.
- Do not attempt to open or repair the ZOE. Contact your dealer for help if it becomes defective.
- Handle with care! Do not throw! Do not drop!

Warranty

- The ZOE-ENG-12 is covered by a 2 years unconditional warranty on all parts.
- For warranty issues or if you have any additional questions, please contact the appropriate bebob distributor listed at www.bebob.de.

Specifications

Model	Zoe-eng-12
Connector	12 pin Hirose
Compatible with	Broadcast 12 pin analog lenses
Zoom speed	stepless
Zoom Direction	Switchable
Record	Yes
Return	Yes
Speed Limiter	Yes
Clamping	On pan-arms up to 34mm Diameter
Extension cables	Up to 15m